



6 [Български] **НУЛИРАЙТЕ БРОЯЧА НА МОДУЛА НА БАРАБАНА**

Уверете се, че устройството е включено.

■ Модели с LCD дисплей

- (1) Натиснете едновременно **OK** и **▲**.
- (2) Натиснете **OK**, за да изберете Барабан.
- (3) Натиснете **OK**, за да изберете цвета на тонера за модула на барабана, който току що сте сменили.
- (4) Натиснете **▲**, за да нулирате брояча на барабана.

■ Модели със сензорен екран

- (1) Натиснете **☒**.
- (2) Натиснете и задръжте **■** за пет секунди.
- (3) Натиснете Барабан.
- (4) Изберете цвета на тонера за модула на барабана, който току що сте сменили, след което натиснете Да.

6 [English] **RESET THE DRUM UNIT COUNTER**

Make sure the machine is turned on.

■ LCD Models

- (1) Press **OK** and **▲** at the same time.
- (2) Press **OK** to select **Drum**.
- (3) Press **OK** to select the toner color for the drum unit you just replaced.
- (4) Press **▲** to reset the Drum counter.

■ Touchscreen Models

- (1) Press **☒**.
- (2) Press and hold **■** for five seconds.
- (3) Press **Drum**.
- (4) Select the toner color for the drum unit you just replaced, then press **Yes**.

