



1. Press the front door release button.

Figure : Press the front door release button




2. Open the front door.

Figure : Open the front door




3. Remove the used toner cartridge from the printer.

Figure : Remove the cartridge from the printer




4. Remove the new toner cartridge package from the box, and then pull the release tab on the packaging.

Figure : Pull the release tab on the packaging




5. Remove the toner cartridge from the opened packaging shell. Place the used toner cartridge in the shell for recycling.

Figure : Remove the cartridge from the opened packaging




6. Hold both ends of the toner cartridge and rock it 5-6 times.

Figure : Shake the toner cartridge




7. Align the toner cartridge with the tracks inside the printer, and install the toner cartridge until it is firmly seated.

Figure : Install the cartridge



8. Close the front door.

Figure : Close the front door




1. Press the front door release button.

Figure : Press front door release button




2. Open the front door.

Figure : Open front door




3. Remove the used toner cartridge from the printer.

Figure : Remove toner cartridge




4. Remove the new toner cartridge package from the box, and then pull the release tab on the packaging.

Figure : Pull release tab on cartridge packaging




5. Remove the toner cartridge from the opened packaging shell. Place the used toner cartridge in the shell for recycling.

Figure : Remove cartridge from opened packaging




6. Hold both ends of the toner cartridge and rock it 5-6 times.

Figure : Shake the toner cartridge



7. Align the toner cartridge with the tracks inside the printer, and install the toner cartridge until it is firmly seated.

Figure : Install the cartridge



8. Close the front door.

Figure : Close front door

